

# ESCORT BLOWING COOLING KIT

1. Disconnect +ve battery terminal, drain water system and remove the top/bottom water hoses. Remove radiator and original fan
2. Assemble the fan (1) and brackets (2) with the M6 hex screws (4), M6 washers (5) and M6 nuts (6). Make sure the bracket is behind the mounting points on the fan i.e. the fan should be on the radiator side of the brackets as shown below

An extra pair of hands would be very helpful at this stage

3. Push the fan assembly (1,2,4,5,6) onto the front of the radiator (3) locating it between the radiator and the bulkhead using the original radiator mounting position in the car, use the original mounting bolts to attach the assembly in place
4. Mount the fan controller in the top hose and refill the water system
5. Follow the EFC instructions supplied for fitting information and setup

